Denwa
UNIFIED COMMUNICATIONS

DENWA
DW-V-AXT

QUICK INSTALLATION GUIDE

Waterproof   Plug

61.2

Screw holes

Screw

173

45

Build-in box

Network switch

CAT 5e

Exit button

EX-BUT1
EX-BUT2

XL-6017

+12V
GND

ON
COM
NC

Lock

Power Supply

+12V
GND
+18V
CTRL
LOCK1
LOCK2

Power (UPS-DP/P)

3. BASIC SETTING

Switch

PC

Outdoor panel

Make sure the PC and Door Phone are in the same network, segment, through and web bowser to access the phone with it`s default ip: 192.168.1.100, config the account and dtmf code to make a call and open the door.